

Nr. desen	COD	denumire	buc.
1	WR6006-1600-300-21	Φ200 wheel cover	2
2	GB845-85	Φ8*Φ16*1.5 gasket	2
3	WR6006-1600-700-13	Front Wheel Bracket Assembly Press Plate	2
4	WR6006-1600-400-08	6006 Front Axle Welding Diagram	1
4-1	WR6006-1600-700-14	Gear Adjustment Trigger	1
4-2	WR6006-1600-700-02	6006 front axle	1
4-3	WR6006-1600-700-15	Gear Adjustment Trigger Lever Assembly	1
4-4	WR6007-1840-700-08-A	Gear Adjustment Shrapnel	1
5	WR6006-1600-300-20	Φ200 wheel	2
6	WR6036-1800-700-01	Grass blade	1
7	WR6006-1600-700-08	Filter sponge NO.2	1
8	WR6006-1600-700-07	Filter sponge NO.1	1
9	WR6006-1600-700-09	Filter sponge NO.3	1
10	GB845-85	Square Nuts 12*12*6 M8	2
11	WR8001-1400-300-24	Cable Plate Assembly	1
12	WR6006-1600-300-13	Windscreen	1
13	WR6036-1800-300-01	6036 housing cover	1
14	WR6036-1800-300-02	6036 housing handle	1
15	WR6601-300-19	DC Collection Bag Cover Pins	1
16	WR6006-1600-400-04	Torsion spring	1
17	WR6036-1800-300-03	6036 collection bag cover	1
18	WR6006-1600-300-16	Torsion spring fixing pin	1
19	WR6007-1840-500-02	Protector 17AMD/105G+PTC	1
20	WR6006-1600-300-22	Sandbag	1
20-1	WR6006-1600-300-24	PE bag	1
20-2		Sand	1
21	WR6006-1600-300-01	Base	1
22	WR6006-1600-400-03	Back wheel spindle	2
23	GB845-85	Screw ST5*25	2
24	WR6002-1500-300-03	Φ150 wheel	2

Nr. desen	COD	denumire	buc.
26	WR8018-1500-300-12	Wheel cover	2
27	GB845-85	Cross recessed pan head screws ST3*12	3
28	GB845-85	Hexagon socket locknuts M5	1
29	WR6006-1600-300-08	Bearing block	1
30	GB845-85	Screw M5*25	1
31	GB845-85	Hexagon socket locknuts	1
(31)	GB845-85	Inner hexagon spanner	1
32	GB845-85	Screw ST4*20	2
33	WR6006-1600-300-09	Bearing seat pressure plate	1
34	WR6006-1600-300-10	Blade quick release locking knob	1
(34)	GB845-85	Hexagon socket head cap screws with spacers M6*35	1
35	WR6006-1600-300-07	Depth adjustment handle (right)	1
36	WR6006-1600-300-06	Depth adjustment handle (left)	1
37	GB845-85	Screw ST4*16	10
38	GB845-85	R-pin Ø2*20mm	2
39	WR6006-1600-700-06	Grass collection frame	1
40	WR6006-1600-700-10	Grass collection bag	1
41	GB845-85	Screw ST4*20	11
42	GB845-85	Screw ST5*25	5
43	WR8001-1400-300-35	Knob	4
44	GB845-85	Nut Ø10*19---M6*0.75	4
45	WR8001-1400-300-36	Gasket	4
46	WR6006-1600-700-04	No.2 rod	1
47	GB845-85	Carriage screw M6*53	4
48	WR8001-1400-300-23	Cable strain relief	1
49	WR8001-1400-300-38	New Wire Clamp (Type S)	2
50	WR6006-1600-300-11	No.1 rod seat	2
51	WR6006-1600-700-03	No.1 rod	2
52	GB845-85	Screw ST4.8*14	4

Nr. desen	COD	denumire	buc.
53	WR6006-1600-300-12	Angle adjustment knob	2
54	GB845-85	Hexagon socket head cap screws M8*50	2
100		Motor assembly	1
101	GB845-85	Shaft retaining ring Φ8	1
102	WR6022-1500-300-01	6022 Motor Wind Blades	1
103	GB845-85	Screw ST3*12	2
104	WR8001-1400-600-01	Brushes (T201 extension)	2
105	WR8001-1400-600-02	Carbon Brush holders	2
106	WR6001-1500-300-13	Motor housing	1
107	WR6006-1600-200	Stator assembly	1
107-1	WR6006-1600-500-01	Circular inductors	2
108	GB845-85	Screw ST4*65	2
110	GB/T276-1994	Single row radial ball bearings 608-2RS	2
111	WR6006-1600-100	Rotor assembly	1
112	GB/T276-1994	Single row radial ball bearings 6900-2RS	2
113	WR6001-1500-700-13-01	Red steel paper gasket Φ10.1*22*0.5	2
114	WR6001-1500-700-12	Woolen felt Φ8*Φ16*1.5	1
115	WR6001-1500-400-09	Motor gear box	1
116	GB/T276-1994	Needle roller bearing HK0608	1
117	GB845-85	Shaft retaining ring Φ10	1
118	WR6006-1600-400-05	Small multiribbed pulleys	1
120	WR6006-1600-300-14	Centre bracket	1
122	GB845-85	Screw M4*20	3
123	WR6006-1600-400-06	Output axis	1
124		Multiribbed belt	1
125	WR6006-1600-300-15	Centre bracket cover	1
126	GB845-85	Hexagon socket locknuts	1
127	GB/T276-1994	Single row radial ball bearings (red and black face) 6000-2RS	1
128	WR6001-1500-400-18	wheel	1

Nr. desen	COD	denumire	buc.
129	GB/T276-1994	Single row radial ball bearings (red and black face) 6000-2RS	1
130	GB845-85	Gasket	1
131		Small pulley connecting shaft	1
132	WR6006-1600-400-07	Large gear with output shaft	1
133	WR6001-1500-700-19	Commutator Wool Felt	1
134		Brush Inserts	2
41	GB845-85	Screw ST4*20	3
25	GB845-85	Screw ST4*18	5
200		Switch box assembly	1
201	WR6007-1840-300-18	Trigger seat left	1
202	WR6007-1840-400-09	Wire Trigger Reset Torsion Spring	1
203	WR6007-1840-300-20	Steel wire connecting rodd	1
204	WR6007-1840-300-19	Trigger seat right	1
205	GB845-85	Screw ST4*30	2
206	WR6007-1840-300-15	Switch Box Platen	1
207	WR6007-1840-300-13	Switch box left	1
208	WR6007-1840-500-01	Wire	1
209	WR8001-1400-500-05H	Cable with plug	1
210	WR8001-1400-300-25	Cable sheath	1
211	GB845-85	Screw ST4*18	6
212		Boat Switch	1
213	WR8001-1400-400-29	Spring	1
214	WR6007-1840-300-16	Switch trigger	1
215	WR8001-1400-500-06	Capacitance	1
216	WR6007-1840-300-17	Switch button	1
217	WR6007-1840-300-14	Switch box right	1
218	WR6006-1600-700-05	No.3 rod	1
219		Sponge casing	1
220	WR6007-1840-700-14	Wire trigger	1

Nr. desen	COD	denumire	buc.
41	GB845-85	Screw ST4*20	3
11	WR8001-1400-300-24	Cable Plate Assembly	2
300		Aerator assembly (8 blades)	1
301	WR6001-1500-400-05	Coupling head	1
302	GB845-85	Shaft head gasket	1
303	WR6006-1600-400-02	Blade iron bushing short	1
304	GB845-85	Cylindrical pins with elasticity	1
305	WR6006-1600-700-01	blades	8
306	WR6006-1600-300-23	8 Blade Plastic Bushing	7
307	WR6006-1600-400-01	Blade iron bushing length	1
308	WR6001-1500-400-18-01	Dust cover left	1
309	WR6001-1500-700-05	Square Tube Protection Gasket	1
310	WR6006-1600-700-12	Blade Square Tube Shaft	1
311	GB/T276-1994	Single row radial ball bearings	1
117	GB845-85	Shaft retaining ring	1
400		Scarifier Assembly	1
401	WR6001-1500-300-16	Claw spring holder cover	13
402	WR6001-1500-300-17	Claw Spring Holder	11
403	WR6001-1500-400-04	Claw spring	24
404	WR6006-1600-700-11	Square tube shaft for raking blades	1
405	WR6006-1600-300-25	Claw Spring Holder	1
406	GB845-85	Shaft head gasket	1
407	WR6006-1600-204-01	Dust cover for new raking blades	1
117	GB845-85	Shaft retaining ring	1
311	GB/T276-1994	Single row radial ball bearings	1
301	WR6001-1500-400-05	Coupling head	1
302	GB845-85	Shaft head gasket	1
308	WR6001-1500-700-18-01	Dust cover right	1